



# UP-GWS01 BT module installation SOP


Module Kit P/N : UP-BTKIT-A10-0001

**Presenter** : Irene Lin

**Date** : 2017.06.21


# SOP

- Step 0 : Bluetooth module, BT IPEX cable, BT antenna, BT/WiFi Y cable, sponge\*3, metal bracket for BT, screw\*2
- Apply the sponge to module and bracket first




# SOP

- Step 1 : Connect the BT module by the smaller BT cable
- Warning : Connect side A(with parts) of BT module up with side B'(without" ▲ ") of BT port up. **The BT module can be burned out if it's connected in the wrong way.**




# SOP

- Step 2 : Put BT module on the base and fix the metal bracket on top of it with screws




# SOP

- Step 3 : Insert WiFi/BT Y cable into UP-CHT01 via port per image illustrated




# SOP

- Step 4 : Buckle the BT IPEX cable into BT module per image illustrated



# SOP

- Step 5 : Secure the BT IPEX cable onto the chassis per illustration below



# SOP

- Step 6 : Tight the bolt and fix BT antenna



# SOP

- Step 7 : Fasten the screws on the chassis



# SOP

- Step 8 : Done



# Thank You